



WIRE INSTALLATION TOOL INSTRUCTIONS (R72023)



Models: ANY PERFORMAX OR EV² GAUGE

- 1 Note the side of the tool with the raised pegs (arrows in Fig 1 & Fig 2). This corresponds to pin #6 (EV2) or #4 (Performax) on the connector.
- 2 Place the wires in the slots of the tool, starting with pin #6 (or #4).
- 3 Place the connector over the wires and the tool, making sure pin #6 (or #4) is at the side with the raised pegs, and keeping the wires in the slots.
- 4 Using pliers, carefully squeeze the connector into the insertion tool, until it is fully seated and all the wires are pushed into their slots in the connectors (Fig 2).

Note: Fig 2 shows an EV2 6-pin connector. The insertion tool is compatible with Performax 4-pin connectors.



Form No. IS190 (Rev. B 05/29/2009)

ISSPRO, INC. • 2515 N.E. Riverside Way • Post Office Box 11177 • Portland, Oregon 97211-1899
503-288-4488 • 800-888-8065 • Fax: 503-249-2999 www.isspro.com © 2008 ISSPRO, Inc. All Rights Reserved.



WIRE INSTALLATION TOOL INSTRUCTIONS (R72023)



Models: ANY PERFORMAX OR EV² GAUGE

- 1 Note the side of the tool with the raised pegs (arrows in Fig 1 & Fig 2). This corresponds to pin #6 (EV2) or #4 (Performax) on the connector.
- 2 Place the wires in the slots of the tool, starting with pin #6 (or #4).
- 3 Place the connector over the wires and the tool, making sure pin #6 (or #4) is at the side with the raised pegs, and keeping the wires in the slots.
- 4 Using pliers, carefully squeeze the connector into the insertion tool, until it is fully seated and all the wires are pushed into their slots in the connectors (Fig 2).

Note: Fig 2 shows an EV2 6-pin connector. The insertion tool is compatible with Performax 4-pin connectors.



Form No. IS190 (Rev. B 05/29/2009)

ISSPRO, INC. • 2515 N.E. Riverside Way • Post Office Box 11177 • Portland, Oregon 97211-1899
503-288-4488 • 800-888-8065 • Fax: 503-249-2999 www.isspro.com © 2008 ISSPRO, Inc. All Rights Reserved.